

The Dishlex white freestanding dishwasher is equipped with a rotary dial and 5 wash programs, including 30 minutes quick wash and water saving ECO wash. Enjoy the added benefits of a half load wash and stable support for tall glasses.

RRP AUS \$799.00





Product Details

FEATURES

13 place settings	Half load option	Wash progress indicator	Adjustable upper basket
Water safety system	Durable stainless steel tub		

BENEFITS

Simple to use controls

The well-designed rotary dial saves time and reduces confusion. Simply rotate it to select your desired program.

A faster wash

When you're in a hurry or only have a partial load to wash, the Quick 30 program is the perfect choice. This 60-degree wash ensures sparkling dishes every time.

Saves water

With today's climate challenges, we need to do what we can to save water. That's why we offer 4-star WELS water rated dishwashers that only use 11.7 litres of water, just a fraction of the water you will use when hand washing dishes.

More stable with soft spikes

Now you can prevent glasses from falling over, breaking or cracking in the dishwasher. Our clever soft spikes help keep your glasses stable and reduce the likelihood of breakages.

Load sensing

Load sensing optimises your energy usage. Each load is assessed and adjusted on a wash by wash basis.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Dishwashers	freestanding
Place settings	13
Drying system	condensing
Number of spray arms	2
Top shower	No

SPECIFICATION

Water efficiency star rating WELS	4.5
Water consumption (litres)	11.6
Energy Star Rating	3
Energy consumption cold water (kWhr/yr)	282
Noise level dBA	51
Water supply	cold or hot (maximum 60°C)
Basket colour	grey
Service cord length	1.8

DIMENSIONS

Total height (mm)	850
Total width (mm)	596
Total depth (mm)	625

WASH PROGRAMS

Number of Programs	5
Programs	pots,rinse and hold,Quick 30 min,regular eco,regular plus
Wash option	Half Load



DIMENSIONS

Product height excluding removabale worktop (mm)	820
Product width excluding removabale worktop (mm)	596
Product depth excluding removabale worktop (mm)	570
Height adjustment (mm)	10
Cabinet requirement excluding worktop (height)	822
Cabinet requirement excluding worktop(width)	600
Cabinet requirement excluding worktop (depth)	550
Product height including removal worktop (mm)	850
Product width including removal worktop (mm)	596
Product depth including removal worktop (mm)	625
<u></u>	<u> </u>

WASH PROGRAMS

Range of temperatures	4

CONTROL PANEL

Control panel type	rotary electronic, Push button electronic

FEATURES

Other Features	load sensing



CONTROL PANEL

Top mounted control panel	No
Control panel finish	white
Knob or button finish	white
Display indicators	wash progress,rinse aid,end ,half load ,start

FEATURES

Water safety system	overfill protection,bottom catchment tray
Filter system	3 stage
Dispenser	detergent,rinse aid
Number of spray levels	3

EXTERIOR

Door finish	white
Counter-balance door	Yes
Side colour	white
Plinth colour (kickboard)	white
Removable worktop	Yes
Worktop colour	white

UPPER BASKET

Upper basket features	adjustable top basket,soft spikes for tall glass
Foldable cup shelves	2

LOWER BASKET

Lower Basket Features	cutlery basket	

HOSES

Inlet hose length (metres)	1.5
Drain hose length (metres)	1.5



HOSES

extension hose	spare part

SHIPPING

Shipping Volume (m3)	386
Shipping Weight (Kg)	42
Shipping Weight (Kg)	39.8
Pack Dimensions Height (mm)	894
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	680

STUFFING QUANTITIES

20ft	54
40ft	108
40ft HC	150



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz