

Care 200

Sanitary Compartment For People with Ambulant Disabilities

4.5/3 litre Toilet Suite





A contemporary designed 4.5/3 litre dual flush Care 200 toilet suite installation designed to provide a raised seat height of between 460-480mm for accessible applications £. The pan features a concealed trap which facilitates easy cleaning. The versatility of the Care 200 toilet suite makes it ideal for use by both the ambulant people with disabilities and wheel-chair users including wheeled commode chairs.

Reference must be made to AS 1428.1-2009 with current amendments for Important:

people with ambulant disability requirements. The dimensions in this sheet

may change with amendments to the standard.

Pan: Trident Concealed Trap Care pan 4.5 litre full flush washdown type.

Traps: S-trap unvented only Code No.606310.

Inlet: 50mm back inlet

Seats:

Cistern: Cosmo Care II 4 Star Cistern – A one piece injection moulded tank with a removable

lid. The inlet valve is the Quietflow 2 inlet valve which reduces noise during the filling cycle. Important: Working pressure minimum 30kPa to maximum 1000kPa flow

pressure. Rain water tank compliant.

Buttons: Round Care Button - Plastic (supplied). Other button options sold separately. See

section 16.01 for further details.

Inlet and Inlet is in the RH position and is located on the underside of the cistern and is Overflow: interchangeable. Overflow is internal as standard, an external overflow kit is available.

Caravelle Care seat suppplied, available in Caroma White (W), Sorrento Blue (SB) and

Anthracite Grey (AG). See Section 15 - SEATS for further details.

Refer to below illustration for specific setout dimensions for this suite to meet Position of the Pan: projection requirements for people with ambulant disabilities.

Colours:

Installation: The installation of the toilet suite shall be in accordance with the normal minimum

drainline grade requirements in AS/NZS 3500.2.


Dimensions: All dimensions are in millimetres and are subject to normal manufacturing variations.

Caroma pursues a policy of continuing improvement in design and performance of its products. The right is therefore reserved to vary specifications without notice.

> 650min. - 660max. for ambulant installations







All height dimensions to underside of pan, make allowance for mortar bedding.

Mortar bedding: The pan should be fixed to the floor with a sand cement mixture of 3:1 to a depth of 60mm. When bedded the back of the foot of the pan should be approximately 10mm above the finished floor.

Screw fixing: The pan should be bedded with an acetic cured silicone sealant and fixed with corrosion resistant screws and pan guard washers. Use Caroma pan fixing kit. Code

